

ASLIE Classrooms

To use DVD/VCR Player

1. Turn on Projector (Green Button on Projector remote)
 - a. Press “Video” Button on Projector Remote
2. Turn on DVD/VCR (Red Power button on DVD/VCR remote)
 - a. Press either “DVD” or “VCR” button on DVD/VCR remote.
 - b. Insert DVD or Tape
 - c. Press Play

To use Video Phone on TV

1. Turn on VP (Red Power button on VP remote)
2. Turn on TV (Red power button on TV remote)
 - a. Press “Input” button and use arrows on TV remote to select “Video 1” and press “OK”

To use Video Phone on Projector

1. Turn on VP (Red Power button on VP remote)
2. Turn on Projector (Green Button on Projector remote)
 - a. Press “Video” Button on Projector Remote
3. Turn on DVD/VCR (Red Power button on DVD/VCR remote)
 - a. Press “VCR” on DVD/VCR remote
 - b. Press “Input” on DVD/VCR remote until “L1” is shown on DVD/VCR.