

For Instructors : How to show a DVD or VHS to Projector

- 1. Turn on this DVD/VHS Unit -(press power button).**
 - 2. Press source button on the DVD/VHS Unit and select either DVD or VHS**
 - 3. Turn On Projector (red power button on Projector remote)**
 - a. Press "Source Search" on Projector Remote**
 - 4. Insert video or DVD into DVD/VHS Unit and press play**
-

If Having Problems:

- **Check plug under whiteboard to assure it is plugged in.**
- **Put video or DVD in first and then press source select until correct picture is shown.**

For Instructors: How to use laptop with projector

- 1. Plug white connection cable into laptop**
 - 2. Turn On Projector (red power button on Projector remote)**
 - a. Press "Source Search" on Projector Remote**
-

If Having Problems:

- **Check plug under whiteboard to assure it is plugged in.**
- **Go into "Display Preferences" under "System Preferences" and click the "Detect Displays" button.**